

Geofence

- You can assign the geofence to the vehicle from this panel, please follow the given steps:
- First select a vehicle from vehicle list.
- Then click on 'Assign' button to assign geofence to the vehicle, it will show checkbox against every Geofences.
- Already assign geofence will come as selected. To assign new one please selects checkbox of that geofence

The screenshot displays the 'Geofences' management interface. On the left, a sidebar contains navigation buttons for Alarm Settings, Device Setup, Geofences, Map Notification, Messaging Setup, and Recipient Setup. The main content area is divided into two panels. The left panel shows a 'Vehicles' list with two entries: 'PRLD' (Active Last: 10/05/2021) and 'PRLDEV' (Active Last: 27/09/2021). The right panel is titled 'Assign Geofence' and contains a table with two rows: 'Test 1' and 'Test 2'. In the top-right corner of this panel, there are two checkboxes, both of which are checked. At the bottom of the right panel, there are three buttons: 'Assign' (blue), 'Save' (green), and 'Reset' (red). A red arrow points from the 'Assign' button in the top-right panel to the 'Assign' button in the bottom-right panel. Another red arrow points from the 'Assign' button in the top-right panel to the checkboxes in the 'Assign Geofence' table. A third red arrow points from the 'Assign' button in the top-right panel to the 'Assign' button in the bottom-right panel. A fourth red arrow points from the 'Assign' button in the top-right panel to the 'Assign' button in the bottom-right panel. The breadcrumb at the bottom of the page reads 'Admin > Geofences And Sites'.

- click on 'Save' button for save the details

The screenshot displays the 'Geofences' management interface. On the left sidebar, there are six navigation buttons: 'Alarm Settings', 'Device Setup', 'Geofences', 'Map Notification', 'Messaging Setup', and 'Recipient Setup'. The main content area is titled 'Geofences' and is split into two sections. The 'Vehicles' section on the left includes a search bar and a list of vehicles under the 'COMMON' category. Two vehicles are listed: 'PRLD' (Active Last 10/05/2021) and 'PRLDEV' (Active Last 27/09/2021), each with a radio button for selection. The 'Assign Geofence' section on the right shows a list of geofences: 'Test 1' (checked) and 'Test 2' (unchecked). At the bottom right of the main content area, there are three buttons: 'Assign' (blue), 'Save' (green), and 'Reset' (red). A red arrow points from the 'Save' button to the text 'click on 'Save' button for save the details' above the screenshot. Another red arrow points from the 'Reset' button to the text 'click on 'Reset' button for reset the details' below the screenshot.

- click on 'Reset' button for reset the details