

Mobilize/Immobilize

- Please select vehicle from the left panel then on top menu click on the **'Engine Mobilize'** or **'Engine Immobilize'**.
- If you didn't select any vehicle, it will give you a warning.

The image displays two screenshots of a vehicle management software interface. The top screenshot shows the 'Mobilize/Immobilize' menu with options for 'Engine Mobilize' and 'Engine Immobilize'. The bottom screenshot shows a 'Warning!' dialog box with the message 'Please select at least one asset to send Mobilize command.' and an 'OK' button. Red arrows indicate the flow of the process: from the menu options to the warning dialog.

Search Type Vehicle/Driver Name Advance Search

Vehicle Driver Plan Date Time Speed Location

COMMON

Vehicle	Driver	Plan	Date	Time	Speed	Location
99AMG	Velvet	Credit	23/09/2021	17:01:54	0.00	136, The Avenue, Sunshine West.

Daily Activity Log

Satellites: Date:

Event Time Ign Speed Trip Location

No Record Found.

Map

Mobilize/Immobilize Geofence Nearest Vehicle search for location

Engine Mobilize

Engine Immobilize

Warning!

Please select at least one asset to send Mobilize command.

OK

Google Powered by VIRTUOSO Copyright © 2021-2022 All rights reserved.

Keyboard shortcuts Map data ©2021 Terms of Use Report a map error