

Recipient Setup

Recipient Setup panel have two tabs 1. Add/edit recipient 2. Add/Edit Alerting Rules for LIVE subscriptions 3. Add/Edit Alerting Rules for CREDIT subscriptions

In the Add/edit recipient tab you can add new recipient and see/delete existing.

The screenshot displays the 'Recipient Setup' interface. On the left is a sidebar with navigation options: Maintenance Schedules, Map Notification, Messaging Setup, Recipient Setup (highlighted), Vehicle Setup, and View Driver Detail. The main content area is titled 'Recipient Setup' and contains three tabs: 'Add/Edit Recipient' (selected), 'Add / Edit Alerting Rules For Live subscriptions', and 'Add / Edit Alerting Rules For CREDIT subscriptions'. The 'Add New Recipient' form includes fields for Name, Notes, Mobile Number, and Email ID, each with an 'Add' button. A note at the bottom of the form provides format examples and mentions service charges. The 'Recipient Details' panel on the right shows a search bar and a list of recipient details for a recipient named 'test', including notes, mobile number, and email address. A 'Welcome back' message is displayed at the bottom right of the details panel. At the bottom of the main content area are 'Save' and 'Reset' buttons. The breadcrumb trail at the bottom reads 'Admin > Recipient Setup'.

To Add new recipient fill details like name, notes, mobile number, and email id. Mobile number and email could be multiple if you want to send alert to many people. Click on save button to save the detail.

Inputs And Outputs

- Maintenance Schedules
- Map Notification
- Messaging Setup
- Recipient Setup**
- Vehicle Setup
- View Driver Detail

Recipient Setup

Add/Edit Recipient Add / Edit Alerting Rules For Live subscriptions Add / Edit Alerting Rules For CREDIT subscriptions

Add New Recipient

Name*
Name

Notes
Notes

Mobile Number
Mobile Number **Add**

Email ID
Email Id **Add**

Note:
* Format Examples: 61432111111 [Australia] or 91981000000 [India].
* M-Protok Messaging Service Charges Apply. Setup message bundles using option 'MESSAGING SETUP'.

Recipient Details

Search...

Name test
Notes aaas
Mobile 99999999
Email jainmkas@vhaj.com.au
Action

Welcome back, let us know if you have any questions.

Save **Reset**

Admin > Recipient Setup

Edit recipient: - Click on edit icon in recipient list panel if you want to edit recipient, it will fill the detail in existing box then update details and click on update button to save the updated information.

The screenshot displays the 'Recipient Setup' interface. On the left is a sidebar with navigation options: Maintenance Schedules, Map Notification, Messaging Setup, Recipient Setup (highlighted), Vehicle Setup, and View Driver Detail. The main content area is titled 'Recipient Setup' and contains a breadcrumb trail: 'Add/Edit Recipient > Add / Edit Alerting Rules For Live subscriptions > Add / Edit Alerting Rules For CREDIT subscriptions'. Below this, there are two main panels: 'Add New Recipient' and 'Recipient Details'. The 'Add New Recipient' panel includes fields for Name (test), Notes (aaas), Mobile Number (99999999), and Email ID (jainmkas@vhaj.com.au), each with an 'Add' button and a delete icon. A note at the bottom of this panel states: '* Format Examples: 6143211111 [Australia] or 91981000000 [India]. * M-Protok Messaging Service Charges Apply. Setup message bundles using option 'MESSAGING SETUP''. The 'Recipient Details' panel shows a search bar and a list of two recipients with their respective details and action icons. At the bottom right of the main content area, there are 'Update' and 'Reset' buttons. A red arrow points from the 'Add/Edit Recipient' link to the 'Add New Recipient' form, and another red arrow points from the 'Update' button back to the 'Add/Edit Recipient' link.

Delete recipient: - Click on delete icon to delete recipient in recipient detail panel. **But please note that it will delete all the linked alerting rule.**

Add/Edit Alerting Rules for Live subscriptions:

Here you can setup rule by two type 1. Local 2. Global

Inputs And Outputs

- Maintenance Schedules
- Map Notification
- Messaging Setup
- Recipient Setup**
- Vehicle Setup
- View Driver Detail

Recipient Setup

Add/Edit Recipient **Add / Edit Alerting Rules For Live subscriptions** Add / Edit Alerting Rules For CREDIT subscriptions

Vehicles

Search...

ASSETS

- VR400W 7042
Active Last 29/09/2021

Event Name

Search events...

- Select all events
- BODY DOWN
- BODY UP
- CRASH
- GEO FENCE IN
- GEO FENCE OUT
- IDLING
- INTERNAL BATTERY LOW
- OUTPUT1 RELEASE
- OUTPUT1 TRIGGER
- OVER SPEED
- PANIC
- POWER CUT
- TRANSMISSION ON QUERY

Recipient Name

- test
aaas
99999999
jainmkas@vhaj.com.au
- Test1
999999999999
test@gmail.com

View

VR400W 7042

- Body Down
 - test
- Body Up
 - test

Assign Reset

Admin > Recipient Setup

1. To setup Local, select vehicle, events, and recipient name from the list respectively and click on then assign button.

The screenshot displays the 'Recipient Setup' interface. On the left, a sidebar contains navigation buttons: Maintenance Schedules, Map Notification, Messaging Setup, Recipient Setup (highlighted), Vehicle Setup, and View Driver Detail. The main area is titled 'Recipient Setup' and includes tabs for 'Add/Edit Recipient', 'Add / Edit Alerting Rules For Live subscriptions', and 'Add / Edit Alerting Rules For CREDIT subscriptions'. The interface is divided into four columns: 'Vehicles', 'Event Name', 'Recipient Name', and 'View'. The 'Vehicles' column shows a list of assets, with 'VR400W 7042' selected. The 'Event Name' column lists various events such as 'BODY DOWN', 'BODY UP', 'CRASH', 'GEO FENCE IN', 'GEO FENCE OUT', 'IDLING', 'INTERNAL BATTERY LOW', 'OUTPUT1 RELEASE', 'OUTPUT1 TRIGGER', 'OVER SPEED', 'PANIC', 'POWER CUT', and 'TRANSMISSION ON QUERY'. The 'Recipient Name' column shows a list of recipients, with 'Test1' selected. The 'View' column shows a tree view of the selected vehicle and events, with 'Body Down' and 'Body Up' events visible. At the bottom right, there are 'Assign' and 'Reset' buttons. Red arrows indicate the selection process: one arrow points from the 'Vehicles' list to the 'Assign' button, another from the 'Event Name' list to the 'Assign' button, and a third from the 'Recipient Name' list to the 'Assign' button.

After assigning you will see the tree structure as in below screen.

The screenshot displays the 'Recipient Setup' interface. On the left, a sidebar contains navigation buttons: Maintenance Schedules, Map Notification, Messaging Setup, Recipient Setup (highlighted), Vehicle Setup, and View Driver Detail. The main area is titled 'Recipient Setup' and has three tabs: 'Add/Edit Recipient', 'Add / Edit Alerting Rules For Live subscriptions', and 'Add / Edit Alerting Rules For CREDIT subscriptions'. The 'Add/Edit Recipient' tab is active, showing three panels: 'Vehicles', 'Event Name', and 'Recipient Name'. The 'Vehicles' panel shows an asset 'VR400W 7042' with the status 'Active Last 29/09/2021'. The 'Event Name' panel lists various events with checkboxes, including 'BODY DOWN', 'BODY UP', 'CRASH', 'GEO FENCE IN', 'GEO FENCE OUT', 'IDLING', 'INTERNAL BATTERY LOW', 'OUTPUT1 RELEASE', 'OUTPUT1 TRIGGER', 'OVER SPEED', 'PANIC', 'POWER CUT', and 'TRANSMISSION ON QUERY'. The 'Recipient Name' panel shows two recipients: 'test' (aaas, 99999999, jainmkas@vhaj.com.au) and 'Test1' (99999999999, test@gmail.com). The 'View' panel on the right shows a tree structure for the selected recipient 'VR400W 7042', listing events like 'Body Down', 'Body Up', 'Crash', 'Geo Fence In', 'Geo Fence Out', 'Idling', 'Internal Battery Low', 'Output1 Release', 'Output1 Trigger', 'Over Speed', and 'Panic'. Each event in the tree has a delete icon. At the bottom right of the main area are 'Assign' and 'Reset' buttons. A breadcrumb at the bottom reads 'Admin > Recipient Setup'. A red arrow points from the text above to the tree structure in the 'View' panel.

To delete any event for a recipient, click on delete icon in view panel.

2. To setup global, select all vehicle, all event and recipient name and click on assign button. Then that recipient will set as Global.

The screenshot displays the 'Recipient Setup' interface. On the left is a sidebar with navigation buttons: Maintenance Schedules, Map Notification, Messaging Setup, Recipient Setup (highlighted), Vehicle Setup, and View Driver Detail. The main area is titled 'Recipient Setup' and contains three panels: 'Vehicles', 'Event Name', and 'Recipient Name'. The 'Vehicles' panel shows a search bar and a list of assets, with 'VR400W 7042' selected. The 'Event Name' panel shows a search bar and a list of events, with 'Select all events' checked. The 'Recipient Name' panel shows a search bar and a list of recipients, with 'test' selected. The 'View' panel shows a tree view of the selected vehicle and event, with 'test' assigned to all events. At the bottom right, there are 'Assign' and 'Reset' buttons. The breadcrumb at the bottom reads 'Admin > Recipient Setup'.

Inputs And Outputs

- Maintenance Schedules
- Map Notification
- Messaging Setup
- Recipient Setup**
- Vehicle Setup
- View Driver Detail

Recipient Setup

Add/Edit Recipient Add / Edit Alerting Rules For Live subscriptions Add / Edit Alerting Rules For CREDIT subscriptions

Vehicles

Search...

ASSETS

- VR400W 7042
Active Last 29/09/2021

Event Name

Search events....

Select all events

- BODY DOWN
- BODY UP
- CRASH
- GEO FENCE IN
- GEO FENCE OUT
- IDLING
- INTERNAL BATTERY LOW
- OUTPUT1 RELEASE
- OUTPUT1 TRIGGER
- OVER SPEED
- PANIC
- POWER CUT
- TRANSMISSION ON QUERY

Recipient Name

- test
aaas
999999999
jainmkas@vhaj.com.au
- Test1
9999999999999
test@gmail.com

View

VR400W 7042

- Body Down
 - test
- Body Up
 - test
- Crash
 - Test1
- Geo Fence In
 - Test1
- Geo Fence Out
 - Test1
- Idling
 - Test1
- Internal Battery Low
 - Test1
- Output1 Release
 - Test1
- Output1 Trigger
 - Test1
- Over Speed
 - Test1
- Panic
 - Test1

Assign Reset

Admin > Recipient Setup

After assigning you will see the tree structure as in below screen.

The screenshot displays the 'Recipient Setup' interface. On the left, there is a sidebar with navigation buttons: Maintenance Schedules, Map Notification, Messaging Setup, Recipient Setup (highlighted), Vehicle Setup, and View Driver Detail. The main area is titled 'Recipient Setup' and contains three panels: 'Vehicles', 'Event Name', and 'Recipient Name'. The 'Vehicles' panel shows an asset 'VR400W 7042' with the status 'Active Last 29/09/2021'. The 'Event Name' panel lists various events such as BODY DOWN, BODY UP, CRASH, GEO FENCE IN, GEO FENCE OUT, IDLING, INTERNAL BATTERY LOW, OUTPUT1 RELEASE, OUTPUT1 TRIGGER, OVER SPEED, PANIC, POWER CUT, and TRANSMISSION ON QUERY. The 'Recipient Name' panel shows two recipients: 'test' (999999999, jainmkas@vhaj.com.au) and 'Test1' (999999999999999, test@gmail.com). The 'View' panel on the right shows a tree structure with 'All Vehicle' and 'All Events' nodes. Under 'All Events', there are two entries: 'test' and 'Test1', each with a delete icon. At the bottom right of the main area, there are 'Assign' and 'Reset' buttons. A red arrow points from the text above to the 'Assign' button, and another red arrow points from the text below to the delete icons in the 'View' panel.

To delete any recipient for an event, click on delete icon in view panel.

Same above process applied for credit subscription devices.